


Osso – Beaglebone I/O Expansion cape

Mounting a beaglebone black:


Connect the beaglebone board as in the following picture, with the beaglebone upside down and the Ethernet connector on the same side of the power connector on the Osso board.

Please take care that all the pins are well connected to the beaglebone headers



The beaglebone board will be powered from the Osso cape, you don't need to use the onboard USB nor the power connector of the beaglebone, you just need to give 12VDC (9V to 24V accepted) to the Osso board.

Osso Board connections



For documentation, pinouts, and other questions please refer to:

<https://github.com/nexlab/Osso>

<http://www.nexlab.net/product/osso-beaglebone-io-expansion-cape/>

info@nexlab.net